

Measurement of radon concentration in soil and Verification of radiation hormesis effect in radon radioactivity environment

Hong Keun YOON, Kyu Yeon LEE, Chang Kyun KIM

Department of Environmental Engineering, Inha University

Soil & Groundwater Environmental Lab.

- Introduction
- Sampling
- Analysis the characteristics of Goesan soil
 - Materials and Methods
 - Results
- Experiment of Radon exposure by time and concentration
 - Materials and Methods
 - Results
- Conclusions


Introduction

Introduction

- Occurrence and influence of radon


Occurrence of radon

- Radon is generally emitted in building materials such as concrete and gypsum board, but most of the radon is released in the earth's crust by about 85%.




Characterization of radon

- When uranium in natural materials such as soil or rocks continuously collapses, it becomes radium.
- Finally radon is the radioactive gas that is generated when radium collapses.



Influence of radon



- When the radon enters the lungs by breathing, it can mutate the chromosomes in the cells that cause lung cancer.

Introduction

- Radiation Hormesis effect

Radiation hormesis effect

- It is the hypothesis that **low doses of ionizing radiation are beneficial.**
- It stimulate the activation of repair mechanisms that protect against disease.

Introduction

- Purpose

Purpose of study

- Confirming the radiation hormesis effect of soil microorganisms.
- Proving the radon concentration and exposure time at which the hormesis effect appears.

Sampling

Sampling - Materials and Methods




- Soil samples were collected from radon contaminated sites and three control groups in one mountain in Goesan-gun, Chungcheongbuk-do, South Korea.
- All four points spaced each other 2m apart.
- Soils were collected at 0cm, 15cm, 30cm depth at each site using a sterile shovel.

Analysis the characteristics of Goesan soil - Materials and Methods

Analysis the characteristics of Goesan soil Materials and Methods

- Materials and Methods

1. Radon concentration in Goesan soil




Soil samples from Goesan were placed in a plastic container, sealed well and measured for 1 hour using FRD 400.

Analysis the characteristics of Goesan soil

- Materials and Methods

2. The number of plate culture count (Dilution plate method)




- Analysis for counting the number of microorganisms cultured on a solid medium of a flat plate

Analysis the characteristics of Goesan soil

- Materials and Methods

3. The value of Dehydrogenase measurement




- Indicator of the overall activity of soil microorganism

Analysis the characteristics of Goesan soil - Results

- Radon Concentration Measurement and characteristics of Goesan soil

1. Radon concentration




- Radon contamination sites have the highest radon concentrations in the soil.
- The higher the depth of the soil, the higher the radon concentration.
- Radon concentration in the soil decreases as it moves away from the radon contamination point.

Results and discussion

- Radon Concentration Measurement and characteristics of Goesan soil

2. The number of plate culture count




- The number of plate culture count was the highest in the radon contaminated soil. Also, the number of growing colonies was higher in deep soils.
- These results confirmed the survival of microorganisms can be improved even if the radon concentration is high.

Results and discussion

- Radon Concentration Measurement and characteristics of Goesan soil

3. The value of Dehydrogenase measurement



- The value of dehydrogenase measurement was the highest at the point where the radon concentration was high.
- From these results, it was confirmed that the activity of microorganisms was increased when exposed to radon.

Experiment of radon exposure to Goesan soil by time and concentration

-Materials and Methods

Experimental of Radon exposure by time and concentration

- Materials and Methods

1. Experiment condition

<Experiment Condition>

- Concentration: 14,000 bq/m^3 , 1,400 bq/m^3 , 185 bq/m^3
- Exposure time: 1, 3, 5 hours




Radon gas source



Experimental of Radon exposure by time and concentration

- Materials and Methods

2. Experiment setting



The liquid medium containing the soil microorganisms extracted from each sample




Adjust the radon concentration in the chamber

- 14,000 bq/m³
- 1,400 bq/m³
- 185 bq/m³

Experimental of Radon exposure by time and concentration

- Materials and Methods

3. OD 600




- Analysis for measuring the concentration of bacteria or other cells in a liquid

Experimental of Radon exposure by time and concentration

- Materials and Methods

4. COD



- Used to measure the degradation ability of the microorganisms exposed to radon


Experiment of radon exposure to Goesan soil by time and concentration

-Results

Results and discussion

- Radon exposure experiment results by concentration and time

1. The number of plate culture count & The value of Dehydrogenase measurement – 185 bq/m^3




- When exposure concentration is 185 bq/m^3 , the number of plate culture count and the value of dehydrogenase measurement increase by increasing exposure time.
- These results show that as radon exposure increase, the number and activity of microorganism increase.

Results and discussion

- Radon exposure experiment results by concentration and time

1. The number of plate culture count & The value of Dehydrogenase measurement – $1,400\text{bq}/\text{m}^3$




- When exposure concentration is $1,400\text{bq}/\text{m}^3$, the number of plate culture count and the value of dehydrogenase measurement increase by increasing exposure time from 1hr to 3hr.
- But increasing exposure time from 3hr to 5hr, the number of plate culture count and the value of dehydrogenase measurement decrease.

Results and discussion


- Radon exposure experiment results by concentration and time

1. The number of plate culture count & The value of Dehydrogenase measurement – 14,000 bq/m^3


(a) 14,000 bq/m^3 , 1hr exposure



(b) 14,000 bq/m^3 , 3hr exposure



(c) 14,000 bq/m^3 , 5hr exposure




- When exposure concentration is 14,000 bq/m^3 , the number of plate culture count and the value of dehydrogenase measurement decrease by increasing exposure time.
- The maximum value was shown at 1 hour exposure, and the longer the exposure time, it did not grow well due to adverse effects on microorganism growth.

Results and discussion

- Radon exposure experiment results by concentration and time

1. The number of plate culture count & The value of Dehydrogenase measurement – 3hr exposure




- As compare all results of experiment, the value of the all radon contamination point is the maximum when exposure time is 3hr.
- As a result, when radon concentration is 1,400bq/m³ and exposure time is 3hr, results show the highest growth of microorganism.

Results and discussion


- Radon exposure experiment results by concentration and time

2. The value of OD 600 – 3hr exposure


(b) 185 Bq/m^3 , 3hr exposure



(b) 1,400 Bq/m^3 , 3hr exposure



(b) 14,000 Bq/m^3 , 3hr exposure




- The value of OD 600 at all experiment conditions shows almost same increase/decrease trends as the number of plate culture count and the value of dehydrogenase measurement.
- Compared all the value of OD 600 of 3hr exposure time experiment.
- As a result, when radon concentration is 1,400 Bq/m^3 , the value of OD 600 also shows the highest growth of microorganism.

Results and discussion


- Radon exposure experiment results by concentration and time

3. The value of COD


(a) 185 bq/m^3 exposure



(b) 1,400 bq/m^3 exposure



(c) 14,000 bq/m^3 exposure




- When radon concentration is 1,400 bq/m^3 and exposure time is 3hr, the rate of carbon decomposition was highest for 83%.
- As a result, it confirm that the carbon decomposition ability was improved due to the promotion of microbial activity when exposed to a slightly high concentration of radon.

Results and discussion


- Discussion

Total results – $1,400\text{bq}/\text{m}^3$, 3hr


(a) Dilution plate method & Dehydrogenase analysis



(b) OD 600 measurement



(c) COD



- Three results prove that the conditions of radon concentration $1,400\text{bq}/\text{m}^3$ and exposure time 3hr appears highest growth of microorganism and highest carbon decomposition.

Conclusions

- In this study, all of the experimental results were confirmed that when exposed to $1,400\text{bq}/\text{m}^3$ of radon concentration makes the better physiological activities of microorganisms compared to exposure to low concentration of $185\text{bq}/\text{m}^3$ and high concentration of $14,000\text{bq}/\text{m}^3$.
- Based on these results, it was verified that when exposed to a proper concentration of radiation, a beneficial effect can be obtained such as promoted growth reaction or physiological activity of the microorganism.
- In conclusion, this study demonstrated the radiation hormesis effect of radon on soil microorganisms.

Thank you
